

# CMM

## Remote Display for Phocos CA, CML and CMLNL



- Measurement and display panel current, load current and battery voltage.
- Clear, readable 3-digit LCD Display
- 3-position switch to select which value to be displayed
- 3LEDs to show which value is displayed by LCD
- Prepared for DIN rail and wall mounting

Phocos' CMM multi-meter is designed to measure and display panel current, load current and battery voltage of your PV system as true values. This provides you more detailed information of your PV system.

CMM can be used in combination with Phocos CA, CML and CMLNL series charge controllers.

TYPE	CMM
Voltage Range	0 to 35V
Current Range	0 to 25A
Operating Temperature Range	-25 to +50 °C
Length of Connecting Wire	2m
Dimension of Measuring Component	84 x44 x32mm
Dimension of Display Component	72 x 68 x29mm
Weight	195gr (with connecting wire)
Case Protection	IP22

Phocos AG, Germany  
info@phocos.com

Phocos China Ltd., China  
Info-china@phocos.com

Phocos India Solar Pvt. Ltd., India  
Info-india@phocos.com

Phocos Latin America S.R.L., Bolivia  
Info-latinamerica@phocos.com

Phocos Rep. Office Australia, Australia  
Info-australia@phocos.com

Phocos Rep. Office Brazil, Brazil  
Info-brazil@phocos.com

Phocos Rep. Office Eastern Africa, Kenya  
Info-easternafrica@phocos.com

Phocos Eastern Europe S.R.L., Romania  
Info-easterneurope@phocos.com

Phocos SEA Pte Ltd, Singapore  
Info-sea@phocos.com

Phocos Rep. Office South Africa  
Info-sadc@phocos.com

Phocos Tunisia  
Info-maghreb@phocos.com

Phocos USA  
Info-usa@phocos.com